

2.4GHz 14dBi High Gain Dual Polarization Directional Antenna

ANT-FP14D

Installation Guide



1. Package Contents

- ANT-FP14D x 1 unit
- Accessory (including screws and brackets) x 1 set

2. Specifications

Electrical Specifications	
Frequency Range	2.4 ~ 2.5GHz
Max. Gain	14dBi
Antenna Type	Uni-directional, Flat Panel
V.S.W.R.	<1.5
Polarization	Horizontal and Vertical (Dual Polarization)
HPBW / Horizontal	30 degrees
HPBW / Vertical	30 degrees
Input Impedance	50Ω
Connector	N-Type (Female) x 2


Environment & Mechanical Characteristics	
Survival Wind Speed	Greater than 150MPH
Radome Color	Gray-white
Radome Material	ABS, UV resistant
Dimensions (W x D x H)	228 x 15 x 228mm (Connector excluded)
Weight	562g
Weatherproof	IP55
Mount Type	Pole Mount



Outlook:



3. Mounting Configuration



OUTDOOR INSTALLATION WARNING



IMPORTANT SAFETY PRECAUTIONS:

LIVES MAY BE AT RISK! Carefully observe these instructions and any special instructions that are included with the equipment you are installing.

CONTACTING POWER LINES CAN BE LETHAL.

Make sure no power lines are anywhere where possible contact can be made. Antennas, masts, towers, guy wires or cables may lean or fall and contact these lines. People may be injured or killed if they are touching or holding any part of equipment when it contacts electric lines. Make sure there is NO possibility that equipment or personnel can come in contact directly or indirectly with power lines.

Assume all overhead lines are power lines.

The horizontal distance from a tower, mast or antenna to the nearest power line should be at least twice the total length of the mast/antenna combination. This will ensure that the mast will not contact power if it falls either during installation or later.



TO AVOID FALLING, USE SAFE PROCEDURES WHEN WORKING AT HEIGHTS ABOVE GROUND.

Select equipment locations that will allow safe, simple equipment installation.

- Select equipment locations that will allow safe, simple equipment installation.
- Don't work alone. A friend or co-worker can save your life if an accident happens.
- Use approved non-conducting ladders and other safety equipment. Make sure all equipment is in good repair.
- If a tower or mast begins falling, don't attempt to catch it. Stand back and let it fall.
- If anything such as a wire or mast does come in contact with a power line, **DON'T TOUCH IT OR ATTEMPT TO MOVE IT.** Instead, save your life by calling the power company.
- Don't attempt to erect antennas or towers on windy days.

MAKE SURE ALL TOWERS AND MASTS ARE SECURELY GROUNDED, AND ELECTRICAL CABLES CONNECTED TO ANTENNAS HAVE LIGHTNING ARRESTORS. This will help prevent fire damage or human injury in case of lightning, static build-up, or short circuit within equipment connected to the antenna.

- The base of the antenna mast or tower must be connected directly to the building protective ground or to one or more approved grounding rods, using 1 OAWG ground wire and corrosion-resistant connectors.
- Refer to the National Electrical Code for grounding details.

IF A PERSON COMES IN CONTACT WITH ELECTRICAL POWER, AND CANNOT MOVE:

- **DON'T TOUCH THAT PERSON, OR YOU MAY BE ELECTROCUTED.**
- Use a non-conductive dry board, stick or rope to push or drag them so they no longer are in contact with electrical power.
- Once they are no longer contacting electrical power, administer CPR if you are certified, and make sure that emergency medical aid has been requested.