802.11ac 900Mbps Outdoor Wireless CPE

WBS-512AC

Quick Installation Guide

Table of Contents

1. Package Co	ontents	3
2. Physical In	troduction	4
3. Hardware	Installation	5
4. Wired Netv	vork Configuration (Windows 10 and Windows 11)	6
5. Entering in	to the Web Management	7
6. Easy to Se	t Up PtP Connection	8
7. AP Discove	ery through PLANET NMS Controller (NMS-500/NMS-1000V)	9
Further Inform	nation:	11

1. Package Contents

Thank you for choosing PLANET Outdoor Wireless CPE. Before installing, please verify the contents inside the package box.



If there is any item missing or damaged, please contact the seller immediately.

IMPORTANT SAFETY PRECAUTIONS:



Note

- 1. Carefully read the section **"OUTDOOR INSTALLATION WARNING"** in the manual before installation.
- 2. Users **MUST** complete grounding wired with the device; otherwise, a sudden lightning could cause fatal damage to the device. **EMD** (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.

2. Physical Introduction

Hardware Description



DC power jack: 5.5 x 2.1 mm, 12V 1A DC IN



LED Indicators

3. Hardware Installation

Step 1: Push the latch on the bottom of the Outdoor Wireless CPE to remove the sliding cover.





Step 2: Plug the RJ45 Ethernet cable into the PoE Port of the Outdoor Wireless CPE. Then, slide back the cover to finish the installation.





Step 3: Place the mounting strap through the slot on the back of the Outdoor Wireless CPE and then around the pole. Tighten the mounting strap to secure the Outdoor Wireless CPE.



4. Wired Network Configuration (Windows 10 and Windows 11)

A computer with wired Ethernet connection is required for the first-time configuration of the Wireless AP.

- 1. Click the "Start" button located at the lower-left corner of your computer.
- 2. Select "Control Panel-> Network and Sharing Center".
- 3. Click "Change adapter settings".
- 4. Double-click "Local Area Connection".
- 5. Select "Internet Protocol Version 4 (TCP/IPv4)" and click "Properties".
- 6. Select "Use the following IP address" to configure the IP address to "192.168.1.x" ("x" can be any number from 2 to 254, except 253) and then click the "OK" button to save the configuration.

🕴 Local Area Connection Properties	×	Internet Protocol Version 4 (TCP/IPv4) Properties	x			
Networking Sharing		General				
Connect using: Broadcom NetLink (TM) Gigabit Ethemet		You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.				
Configure This connection uses the following items:		 Obtain an IP address automatically Use the following IP address: 				
Image: Client for Microsoft Networks Image: Client for Microso		IP address: 192 . 168 . 1 . 100				
File and Printer Sharing for Microsoft Networks		Subnet mask: 255 . 255 . 255 . 0				
 ✓ Internet Protocol Version 6 (TCP/IPV6) ✓ Internet Protocol Version 4 (TCP/IPV4) 		Default gateway: 192 . 168 . 1 . 254				
Link-Layer Topology Discovery Mapper I/O Driver Link-Layer Topology Discovery Responder		Obtain DNS server address automatically				
		O Use the following DNS server addresses:				
Install Uninstall Properties		Preferred DNS server:				
Description		Alternate DNS server:				
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.		Validate settings upon exit				
OK Car	ncel	OK Cancel				

5. Entering into the Web Management

Default IP Address: **192.168.1.253** Default SSID: **PLANET_5G**

Step 1: Launch the Web browser and enter the default IP address <u>https://192.168.1.253</u>.



Step 2: Please create a new password according to the guidelines, and then click Apply.

Initializ Change the device manageme	Zation nt password at the first	ogin
New Password		
Confirm Password		
The Password must contain at least numerals,and other symbols only th	8 characters (Max. 32 ch is 5 character @,#,*_, an Apply	aracters), including upper case, lower case, d - can be accepted.

The Password must contain at least 8 characters (Max. 32 characters), including upper case, lower case, numerals and other symbols. Only these 5 characters like $@, #, *, _, and - can be accepted$.

6. Easy to Set Up PtP Connection

- Step 1: (1) Position "Master" to "Slave" on the AP.
 - (2) Press the **"Reset/Pair"** button on both APs to be connected in **2 minutes**.
 - (3) The connection has been successfully established.

3 Steps to Set Up PtP Connection



7. AP Discovery through PLANET NMS Controller (NMS-500/NMS-1000V)

The WBS-512AC is the Smart AP series which can be centrally managed by PLANET NMS Controller.

Follow the steps below to discover the managed AP through PLANET NMS controller (NMS-500/NMS-1000V). Please ensure each managed AP uses a different static IP in the same subnet before physically connecting to the managed network.

*** Please regularly check PLANET website for the latest compatibility list of the controllers and managed APs in each firmware version.

- Step 1: Launch the Web browser (Google Chrome is recommended.) and enter the default IP address <u>https://192.168.1.100:8888</u> of the NMS controller. Then, enter the default username and password "admin" to log in to the NMS setup wizard.
 - * The secure login with SSL (HTTPS) prefix is required.

👼 https:/	/192.168.1.100:8888 ×	[×
$\leftrightarrow \ \Rightarrow \ G$	① https://192.168.1.100:8888	*	⊳ ⊲	
	Authentication required https://192.168.1.100:8888 Username admin Password •••••			
	Log in Cancel			

Step 2: After finishing the setup wizard, please go to the "Domain" page to discover and add the managed AP to the device list. Then, go to the "AP Control→AP Management" page to configure pre-defined profiles to the managed AP without logging on to the AP's web page.



For information about further configuration of Managed AP by using PLANET Smart AP Control, refer to the configuration guide of the NMS controller (NMS-500/NMS-1000V).

Further Information:

The above steps introduce the simple installations and configurations of the device. For further configurations, please refer to the user manual, which can be downloaded from the website.

WBS-512AC: <u>https://www.planet.com.tw/en/support/downloads?&method=keyword&keyword</u> <u>=WBS-512AC&view=3#list</u>



PLANET Network Management Solution (NMS): https://www.planet.com.tw/en/products/network-management



If you have further questions, please contact the local dealer or distributor where you purchased this product.