# Dual Band 802.11ax 3000Mbps Ceiling-mount Wireless Access Point w/802.3at PoE+ and 2 10/100/1000T LAN Ports

### WDAP-C3000AX

Quick Installation Guide

# **Table of Contents**


| 1. Pa | ackage Contents  | 3 |
|-------|--|---|
| 2. P  | hysical Introduction   | 1 |
| 3. H  | lardware Installation  | 5 |
| 4. C  | Connecting the AP (for Windows OS)                             | 5 |
| 5. W  | Vired Network Configuration (Windows 10 and Windows 11)        | 7 |
| 6. E  | ntering into the Web Management                                | 3 |
| 7. W  | Vireless Network Connection                                    | ) |
| 8. A  | P Discovery through PLANET NMS Controller (NMS-500/NMS-1000V)1 | L |
| 9. P  | LANET CloudViewerPro App (Android & iOS)12                     | 2 |
| Furtl | her Information:   | 1 |

# 1. Package Contents

Note

Thank you for choosing PLANET WDAP-C3000AX. Before installing the AP, please verify the contents inside the package box.

The WDAP-C3000AX should contain the following items in the package:




# 2. Physical Introduction

### **Front Panel**




#### **Rear Panel**




### 3. Hardware Installation


**Step 1:** Take the mounting bracket, put it on the target place by aligning the holes and fix it with the supplied screws.



**Step 2:** Load the device into the mounting bracket, and be sure the device is mated with fixed screws. Then, lock the device in position and plug the Ethernet cable into the WDAP-C3000AX.



**Step 3:** Plug the other end of the Ethernet cable into the PoE switch.



### 4. Connecting the AP (for Windows OS)

As the default setting of connection type of WDAP-C3000AX is DHCP, your computer's IP address has to be the same network segment as the wireless AP. To find the IP address of the AP, use the utility of "Smart Discovery Lite", which can be found on PLANET official website.

- 1. Launch the utility from your computer after you have downloaded and decompressed it.
- 2. Select your adapter to connect the AP.
- 3. Click the "Refresh" button.
- 4. The AP model and its IP address are shown.
- 5. Check whether the IP address of your adapter and the IP address of the AP are the same.
- 6. If yes, click "Connect to Devices" for the AP setting.
- 7. If no, go to the next page to set your wired or wireless setting.
- 8. If there is no DHCP server in the local network, the IP will go back to 192.168.1.253 by default after 60 seconds.

| ( | 🌛 PLANET Smart D  | iscovery Lite  |                   |               |             |               |               |              |            |          | ×        |
|---|-------------------|----------------|-------------------|---------------|-------------|---------------|---------------|--------------|------------|----------|----------|
| F | File Option Hel   | р              |                   |               |             |               |               |              |            |          |          |
|   |                   |                | U Refree          | sh            | 🖹 Exit      |               |               |              | PL Retwork |          |          |
|   | MAC Address       | Device Name    | Version           | DevicelP      | NewPassword | IP Address    | NetMask       | Gateway      | Descript   | tion     |          |
| 1 | A8-F7-E0-03-C3-00 | WDAP-C3000AX   | v1.2305b23072     | 192.168.1.253 |             | 192.168.1.253 | 255.255.255.0 | 0.0.0.0      | Indoor 3   | 3000AX W | /ireless |
|   |                   |                |                   |               |             |               |               |              |            |          |          |
|   |                   |                |                   |               |             |               |               |              |            |          |          |
|   |                   |                |                   |               |             |               |               |              |            |          |          |
|   |                   |                |                   |               |             |               |               |              |            |          |          |
|   |                   |                |                   |               |             |               |               |              |            |          |          |
|   | Select Adap       | ter: 192.168.0 | .143 (90:E8:68:50 | D:D1:8B)      |             | •             | Control Pac   | ket Force Br | oadcast    |          |          |
|   |                   | U              | pdate Device      | Update Multi  | Upda        | te All        | Connect to    | Device       |            |          |          |

## 5. Wired Network Configuration (Windows 10 and Windows 11)

A computer with wired Ethernet connection is required for the first-time configuration of the wireless AP.

- 1. Click the **"Start"** button located at the lower-left corner of your computer.
- 2. Click "Control Panel".
- 3. Double-click the "Network and Sharing Center" icon.
- 4. Click "Change adapter settings".
- 5. Double-click "Local Area Connection".
- 6. Select "Internet Protocol Version 4 (TCP/IPv4)" and click "Properties".
- Select "Use the following IP address" and then click the "OK" button twice to save the configuration. For example, the default IP address of the WDAP-C3000AX is 192.168.1.253 and the router is 192.168.1.254. You may choose from 192.168.1.1 to 192.168.1.252.

| Local Area Connection Properties  | Internet Protocol Version 4 (TCP/IPv4) Properties   | ? ×     |  |  |  |  |  |
|---|---|---------|--|--|--|--|--|
| Networking Sharing  | General   |         |  |  |  |  |  |
| Connect using:  | You can get IP settings assigned automatically if your network supports<br>this capability. Otherwise, you need to ask your network administrator<br>for the appropriate IP settings. |         |  |  |  |  |  |
| Configure This connection uses the following items:   | <ul> <li>Obtain an IP address automatically</li> <li>Output use the following IP address:</li> </ul>  |         |  |  |  |  |  |
| Client for Microsoft Networks   | IP address: 192 . 168 . 1 .   | 100     |  |  |  |  |  |
| File and Printer Sharing for Microsoft Networks   | Subnet mask: 255 . 255 . 255 .  | 0       |  |  |  |  |  |
| Internet Protocol Version 6 (TCP/IPv6)     ✓ Internet Protocol Version 4 (TCP/IPv4)   | Default gateway: 192.168.1.   | 254     |  |  |  |  |  |
| Link-Layer Topology Discovery Mapper I/O Driver     Link-Layer Topology Discovery Responder   | Obtain DNS server address automatically   |         |  |  |  |  |  |
|   | O Use the following DNS server addresses:   |         |  |  |  |  |  |
| Install Uninstall Properties  | Preferred DNS server:   |         |  |  |  |  |  |
| Description   | Alternate DNS server:   |         |  |  |  |  |  |
| Transmission Control Protocol/Internet Protocol. The default<br>wide area network protocol that provides communication<br>across diverse interconnected networks. | Validate settings upon exit   | dvanced |  |  |  |  |  |
| OK Cancel   | ОК  | Cancel  |  |  |  |  |  |

### 6. Entering into the Web Management

Default IP Address: **192.168.1.253 (The default IP address will be 192.168.1.253 if there is no DHCP server in the local network.)** Default SSID (2.4GHz): **PLANET\_2.4G** Default SSID (5GHz): **PLANET\_5G** 

Step 1: The Web management allows you to access and manage the wireless AP easily. Launch the Web browser and enter the default IP address <u>http://192.168.1.253</u>.

| Attp://192.168.1.253/               | 🗯 Safari File Edit View History |
|-------------------------------------|---------------------------------|
| C 192.168.1.253 ×                   |                                 |
| File Edit View Favorites Tools Help | + http://192.168.1.253/         |




This login method is based on the firmware version before **September 2024**.

**Step 2-1:** When the following dialog box appears, please enter the default user name and password.

```
Default Username: admin
Default Password: admin
```

Then please perform subsequent operations according to Step 3.



For security reasons, it is recommended to change the password at the first login and memorize it.



This login method is based on the firmware version of **September 2024** or after.

### Step 2-2:

Default Username: **admin** Default Password: **ap + the last 6 characters of the MAC ID in lowercase** 

Find the MAC ID on your device label. The default password is "ap" followed by the last six lowercase characters of the MAC ID.



MAC ID: A8F7E0XXXXXX Default Password: apxxxxxx ("x" means the last 6 digits of the MAC address. All characters should be in lowercase.)

**Step 2-3:** After logging in, you will be prompted to change the initial username and password to a permanent one.

The Password must contain 8 to 31 characters, including uppercase, lowercase, numerals and other symbols. Please note spaces (blanks) are not accepted.

| STEP 1 - Accour   |                    |                       |                            |                    |             |
|-------------------|--------------------|-----------------------|----------------------------|--------------------|-------------|
| Account           | 2<br>Mode          | LAN                   | 4<br>Wireless Connection   | Wireless           | Completed   |
| Jsername          |                    | admin                 |                            |                    |             |
| assword           |                    |                       |                            |                    |             |
| Confirm Password  |                    |                       |                            |                    |             |
| The password must | contain 8~31 chara | acters, including upp | per case, lower case, nume | rals and other sym | nbols       |
|                   |                    |                       |                            |                    | Cancel Next |

**Step 3:** Please follow the wizard to do the first-time setup and select the mode preferred.

### 7. Wireless Network Connection

Step 1: Right-click on the **network icon** displayed in the system tray.



**Step 2:** Highlight the wireless network (SSID) to connect and click the **[Connect]** button.



**Step 3:** Enter the **encryption key** of the WDAP-C3000AX if necessary.

You have already finished the configuration of the WDAP-C3000AX. Now you can use your smart phone, tablet, laptop, or any other Wi-Fi device to connect with it wirelessly and start surfing the internet.

# 8. AP Discovery through PLANET NMS Controller (NMS-500/NMS-1000V)

The WDAP-C3000AX is the Smart AP series which can be centrally managed by PLANET NMS Controller.

Follow the steps below to discover the managed AP through PLANET NMS controller (NMS-500/NMS-1000V). Please ensure each managed AP uses a different static IP in the same subnet before physically connecting to the managed network.

\*\*\* Please regularly check PLANET website for the latest compatible list of the controller/managed APs in each firmware version.

- Step 1: Launch the Web browser (Google Chrome is recommended.) and enter the default IP address <u>https://192.168.1.100:8888</u> of the NMS controller. Then, enter the default username and password "admin" to log on to the system.
  - \* The secure login with SSL (HTTPS) prefix is required.



**Step 2:** Go to the "Domain" page to discover and add the managed AP to the device list. Then, you can go to the "AP Control -> AP Management" page to configure predefined profiles to the managed AP without logging on to the AP's web page.

| VR-300P              |    |            | 🔅 System         | 🚱 Network        | Security  | P VPN | AP Control   | 🕫 PoE 🎤 Mainte | nance         |                    |           | Auto Logout | ⊻C ₽ |
|----------------------|----|------------|------------------|------------------|-----------|-------|--------------|----------------|---------------|--------------------|-----------|-------------|------|
| Preference           |    |            |                  |                  |           |       |              |                | <b>A</b>      | Elliss by Ocertant | 0         | 40.440.0    |      |
| AP Search            |    | nagement   |                  |                  |           |       |              | T              | ද 💼 App       | Filter by Context  | Q         | 10 (106     | 4)   |
| AP Management        | Or | nline 🔵 Of | ffline O Disable |                  |           |       |              |                |               |                    |           |             |      |
| AP Group Management  |    | Status     | AP Group         | MAC Address      | Device Ty | /pe   | Model No.    | Version        | IP Address    | Device Description | $\square$ | Action      |      |
| SSID Profile         |    | •          |                  | a8:f7:e0:00:30:e | 0 Wireles | is    | WDAP-C3000AX | v1.2305b230809 | 192.168.0.147 |                    | 2 8       |             | ¢.   |
| Radio 2.4GHz Profile |    |            |                  |                  | 2         |       |              | 2 <sup>7</sup> |               |                    |           | 0 9         | 8    |

For information about further configuration of Managed AP by using PLANET Smart AP Control, refer to the configuration guide of the NMS controller (NMS-500/NMS-1000V).

## 9. PLANET CloudViewerPro App (Android & iOS)

The WDAP-C3000AX is the Smart AP series which can be monitored by PLANET CloudViewerPro app.

### Step 1: Download PLANET CloudViewerPro app

Get the PLANET CloudViewerPro app from the Apple App Store or Google play, or simply scan the QR code.



#### Step 2: Register

Launch the PLANET CloudViewerPro app and log in with your PLANET CloudViewerPro app. If you don't have an account, register an account with an e-mail address first.



### **Step 3: Bind Devices**

- 1. Log in and go to the device **NMS** page
- 2. Select and enable the PLANET CloudViewer Server Internet function
- 3. Fill in PLANET CloudViewer account (e-mail address) and password.

| VR-100            | 🔅 System 🛛 🛞 Netw             | vork 🕞 Security 🔎 VPN 🖋 Maintenance    |  |  |  |  |  |  |  |  |
|-------------------|-------------------------------|--|--|--|--|--|--|--|--|--|
| Wizard            |                               |  |  |  |  |  |  |  |  |  |
| Dashboard         | MMS Configuration             |  |  |  |  |  |  |  |  |  |
| System Status     | NMS                           | PLANET CloudViewer Server - Internet ~ |  |  |  |  |  |  |  |  |
| System Service    | Email                         | sales@planet.com.tw                    |  |  |  |  |  |  |  |  |
| Statistics        | Password<br>Connection Status | 3<br>*******<br>Success                |  |  |  |  |  |  |  |  |
| Connection Status |                               | Success                                |  |  |  |  |  |  |  |  |
| SNMP              |                               |  |  |  |  |  |  |  |  |  |
| NMS               |                               | Apply Settings Cancel Changes          |  |  |  |  |  |  |  |  |

If CloudViewer server is connected, the connection status will show **success**.

If the server fails to connect, the connection status will show **authentication** failed.

#### Step 4: Log in CloudViewerPro

After you get a Success indication from your device, you may now log in the app again to find your device in the list.



## Further Information:

The above steps introduce the simple installations and configurations of the device. For further configurations, please refer to the user manual, which can be downloaded from the website.

### WDAP-C3000AX

https://www.planet.com.tw/en/support/download. php?&method=keyword&keyword=WDAP-C3000AX&view=3#list



### **PLANET Network Management Solution (NMS):**

https://www.planet.com.tw/en/products/network-management



If you have further questions, please contact the local dealer or distributor where you purchased this product.